


Assembly manual

for Precision Line standard systems




ALVE
components


1A 2 pcs




1B 2 pcs




1C 2 pcs




1D 2 pcs




1E 2 pcs



2 1 pc



3 1 pc




4 2 pcs




5 2 pcs




6 6 pcs




7A 2 pcs



7B 2 pcs




8 2 pc




9 2 pcs




10 4 pcs



11 2 pcs




12A 1 pc



12B 1 pc



12C 1 pc




Assembly manual

for Precision Line standard systems










ALVE
components



for Precision Line standard systems



ALVE
components




Door leaf installation

for Precision Line standard systems




ALVE
components


13 1 pc




14 1 pc



15 1 pc



16 2 pcs



13



2

3



15



1

14




Door leaf installation

for Precision Line standard systems



ALVE
components





Tracks offset information

for Precision Line standard systems



ALVE
components

v.1



v.2

